andis®

# SERVICE PARTS LIST
# MODEL US-1 CLIPPER
# 120 VOLT




| ITEM NO. | PART NO. | DESCRIPTION | QTY. REQ'D |
|---|---|---|---|
| **1** | 201792 | Lower Housing | 1 |
| **2** | | Upper Housing | |
| **2a** | 66189 | Upper Housing - Red (envy) | 1 |
| **2b** | 66249 | Upper Housing - Gold (Fade) | 1 |
| **2c** | 66278 | Upper Housing - Vlack (envy) | 1 |
| **2d** | 66269 | Upper Housing - Met. Red (TackMate) | 1 |
| **2e** | 66289 | Upper Housing - Black (EasyClip) | 1 |
| **2f** | 66309 | Upper Housing - Gray (Barber Combo) | 1 |
| **2g** | 66343 | Upper Housing - Chrome | 1 |
| **3** | 201136 | Housing Screw | 4 |
| **4** | 66303 | Blade Bracket | 1 |
| **5** | 66122 | Lever Arm | 1 |
| **6** | 201001 | Lever Arm Brushing | 1 |
| **7** | 66107 | Lever Arm Screw | 1 |
| **8** | 66319 | Blade Screw | 2 |
| **9** | 200494 | Field Assembly with terminal | 1 |
| **10** | 201134 | Field Screw | 2 |
| **11** | 201038 | Cord and Swtich Kit | 1 |
| **12** | S66127 | Armature Assembly | 1 |
| **13** | 66131 | Hair Guard | 1 |

| ITEM NO. | PART NO. | DESCRIPTION | QTY. REQ'D |
|---|---|---|---|
| **14** | 66394 | Armature Mounting Screw | 2 |
| **15** | 66114 | Power Screw | 1 |
| **16** | 66108 | Power Spring | 1 |
| **17** | 66116 | Spring Pad | 1 |
| **18** | 75296 | Blade Guard | 1 |
| **19** | 66302 | Power Spring - Red | 1 |
| **20** | 200584 | Switch Button | 1 |

**IMPORTANT INFORMATION**

**When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.**

andis

*OUTLINER TRIMMER*
*T-OUTLINER TRIMMER*
*120 VOLT*




| ITEM NO. | PART NO. | DESCRIPTION | QTY. REQ'D |
|---|---|---|---|
| **1** | | Upper/Lower Housing Assembly | |
| **1a** | 200692 | OUT - grey hsgs/red switch -USA | 1 |
| **1b** | 200693 | OUT - grey hsgs/red switch - Canada | 1 |
| **1c** | 200694 | T-OUT - grey hsgs/red switch-USA | 1 |
| **1d** | 200696 | T-OUT - black hsgs/black switch-USA | 1 |
| **1e** | 200697 | OUT - black hsgs/blk swtch-Canada | 1 |
| **1f** | 200698 | T-OUT - grey hsgs/blk swtch-Canada | 1 |
| **1g** | 200699 | T-OUT - grey hsgs/black switch-USA | 1 |
| **1h** | 200701 | OUT - grey hsgs/black switch-USA | 1 |
| **1i** | 200833 | T-OUT LE - blk hsg/blk swtch-US/CAN | 1 |
| **2** | S04527 | Motor Assembly | 1 |
| **3** | 201394 | Tension Spring Assembly | 1 |
| | | | |
| **4** | | Blade Assembly **[Sold Separately]** | |
| **4a** | 04521 | T-blade assembly - Standard | 1 |
| **4b** | 04844 | T-blade assembly - Deep Tooth | 1 |
| **4c** | 200831 | T-blade - Black Limited Edition | 1 |
| **4d** | 04604 | Square Blade | 1 |
| | | | |
| **5** | | Cord Set | |
| **5a** | 04624 | 2 Wire-UL | 1 |
| **5b** | 04617 | 3-Wire-CSA | 1 |

| ITEM NO. | PART NO. | DESCRIPTION | QTY. REQ'D |
|---|---|---|---|
| **6** | | Blade Screws **[set of 2]** | |
| **6a** | 201396 | Blade Mount Screws - Grey | 1 |
| **6b** | 201397 | Blade Mount Screws - Black | 1 |

**IMPORTANT INFORMATION**

**When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.**

Rev-U 3-21-17